

TAB	toggle between LIVE and EDIT mode
~ (tilde)	toggle between LIVE and TRACKER mode
ESC	toggle into SCENE load
ALT-ESC	SCENE write

### LIVE mode

ENTER	execute command
UP	previous command in history
ALT-X	cut command
ALT-C	copy command
ALT-V	paste command
SHIFT-BACKSPACE	clear command

### EDIT mode

]	next script
[	previous script
ENTER	add/overwrite command
SHIFT-ENTER	insert command
ALT-X	cut command (move subsequent lines up)
ALT-C	copy command
ALT-V	paste command
SHIFT-BACKSPACE	clear command

### TRACKER mode

arrows	navigate edit position
ALT-up/down	jump page position up/down
ALT-left/right	jump to top/bottom
ALT-L	jump to position of current pattern length
0-9	numeric entry
-	flip sign
BACKSPACE	divide by 10 (remove least significant digit) until zero
SPACE	toggle non-zero to zero, and zero to one
]	increment value at edit position
[	decrement value at edit position
ALT-X	cut value at index, shift remaining pattern up
ALT-C	copy value at index
ALT-V	paste value at index
SHIFT-ALT-V	insert paste value at index shift remaining pattern down
SHIFT-BACKSPACE	delete index, shift remaining pattern up
SHIFT-ENTER	duplicate current value and shift pattern downwards
ENTER	(if editing index succeeding length) activate next index
SHIFT-L	set pattern length to current position

### SCENE mode (read)

]	next scene
[	previous scene
ENTER	read currently selected scene
arrows	scroll through text

### SCENE mode (write)

arrows (text)	navigation
]	edit text description
[	scroll forward scene write destination
ALT+ENTER	scroll back scene write destination
	write scene

### Global

WIN-(1-8)	manually execute scripts 1 through 8
WIN-M	manually execute METRO script
WIN-I	manually execute INIT script

**monome teletype**

algorithmic ecosystem

<http://monome.org/docs/modular>